

DIRECTIONS FOR BABY

1. Have your toes just touching the floor to get maximum control of the jumper.
2. Have Mum tie a balloon on your Jumper cradle so you can have lots of fun learning to play with a colourful moving object. (use about 12" of string).
3. Another fun activity for hot weather is to get a blow-up wadding pool and place about 4" of water in it. Suspend your Jumper over the pool and you can have lots of fun kicking and splashing in the water. A rotary clothesline is excellent for this activity. If you want to sit right in the water get mum to let the chain right down so you can sit in the water.
4. When using your Jumper be sure to practice all your prewalking skills while bouncing off lots of excess energy each day. You should sleep better and have a better appetite. Finally, you will be giving Mum plenty of worry free time to get her daily jobs done.
5. Don't forget to tell your parents that you are quite big enough to use the Jumper when you are 3 months old (3 months to walking age).

A FINAL WORD

JOLLY JUMPER is simple to install and use. The fore-going instructions are supplied to prevent faulty installation. Every care has been taken to ensure the safety, comfort and happiness of your baby. Each separate part of **JOLLY JUMPER** has been tested thoroughly before being released to you. The manufacturers stand behind their product but will not accept responsibility for accidents due to careless installation or application.

The harness is completely **COLOUR FAST**. Wash whenever required. With ordinary care **JOLLY JUMPER** should last as long as you have babies to bounce. **WASHING INSTRUCTIONS**

To easily wash the saddle of your **JOLLY JUMPER** without having to detach the cord, simply place the saddle inside a pillow case, knot pillow case top, and put in your washing machine.



THE BOUNCE THAT BABIES BEAM ABOUT



ASSEMBLY INSTRUCTIONS

Distributed by:
FITNESSWISE HOLDINGS PTY LTD PO
BOX 317
BROOKVALE NSW 2100
PHONE: (02) 9971 7044
FAX: (02) 9971 7666

Jolly Jumper (NZ) Ltd
PO Box 58-318 Greenmount
Auckland NZ Phone: (09)
274 0443 Fax: (09) 274 0441

In purchasing a **JOLLY JUMPER** you have made a wise investment in increased freedom for yourself - fun and health for your baby. Please give **FULL ATTENTION** to the following instructions so as to make sure you and baby get the most out of this quality product.

ASSEMBLY INSTRUCTIONS

OUR BEST TO YOU

We have assembled the best components that money can buy to make a safe, scientifically designed exerciser for the *'very important baby in your life'*:


Please follow carefully these - **IF**

CEILING HOOK USED


1. Pick spot where baby will be free to maneuver 3 or 4 feet in all directions.
2. Find ceiling joist by tapping with knuckle. Mark spot where hook will go - place piece of scotch tape over spot to prevent cracking of plaster.
3. Screw hook well into ceiling joist.
4. Test hook with adult weight.
5. Hang spring up by looping link of attached chain over hook. Chain is for adjustment.
6. The location of a joist or other heavy material is of the utmost **IMPORTANCE**. Do not trust to thin wood or wall board.
7. In summer the jumper can be suspended from porch, rotary clothesline or sturdy tree in the garden.
8. Be sure to take it along on picnics.

DOOR CLAMP


Another way to use your Jolly Jumper is to suspend it from the casement of your door with the sturdy Door Clamp enclosed with **your** Jumper. (see insert No. 1) Be sure there is a narrow ledge on each side of the door when using the clamp. The Clamp can be easily put in the over lock position and used on trees or rotary clotheslines, thus giving the Jumper complete portability.




Attach the clamp to the door frame as illustrated.




Clip the spring section onto the clamp.



Lay the saddle out flat with the striped webbing out to the sides.




Put baby on the saddle and bring the lower part of the saddle up through the legs. Bring the left then right flap over and attach to the hook and pile fastening. (Make sure this is tight to provide the support needed to hold baby upright and to keep baby's back straight.) Bring the flap down over the hook and pile fastening and dome.



Attach the clips (attached to webbing) to each end of the bar.




Fasten the Jolly Jumper to spring (which is already hanging from hook or door clamp) by placing the palm of your hand under the base of the nylon bar and then lift baby up to the spring and connect the swivel snap to bar.



Adjust the height of the Jolly Jumper so that baby's toes just touch the floor. Use the chain links to adjust height.

WARNING

It is advisable not to place the Jumper near open stairways or over concrete floors. Baby should not be left unattended.



SAFE • STURDY • SUPPORTS 50kgs • MOVED EASILY • NO SCREWS OR NAILS • QUICKLY ATTACHED